

# **IQRF CDC**

**CDC implementation in IQRF USB devices**

## **Technical guide**



Smarter Wireless. Simply.

## CDC class

Unlike the Custom class, the CDC class provides a simpler serial bus via USB interface. A device equipped with the firmware supporting CDC creates a virtual serial port enabling to communicate with PC or another equipment (supporting USB) via the USB interface like through a standard COM port.

Prior to CDC usage, the IQRF USB CDC driver must be installed. It is available to download from [www.iqrf.org/cdc](http://www.iqrf.org/cdc) within the WinUSB and MPUSB drivers installators. For all current IQRF USB devices, the WinUSB should be selected. CDC driver is also installed within the IQRF IDE development environment installation. This driver uses VID / PID by MICRORISC when used with IQRF devices.

IQRF kits working with IQRF IDE use the Custom class but can be switched to/from the CDC class by the IQRF IDE (if the kit is equipped with the CDC option).

### TIP

For testing a communication in CDC mode various SW terminals operating with PC serial ports are available. Select a terminal enabling to issue direct byte commands and data. Recommended terminal: Docklight, [www.docklight.de](http://www.docklight.de). A [project](#) containing all supported commands for this terminal is available. It is necessary just to select the COM port used.

Unsuitable terminals: Windows Hyperterminal, Tera Term, ...

This document describes CDC implementation in IQRF USB devices.

## Communication

Communication is based on *commands* sent from PC and USB device responds with *answers*. Additionally, USB device can send asynchronous *messages* as well.

### Format

Every command begins with the ">" character. Every answer and asynchronous message begins with the "<" character. It allows easy orientation in directions if a PC terminal is used. Every packet is terminated with the CR character (CR LF is also accepted).

#### Command:

> [body] [CR]

#### Answer:

< [body] [CR]

#### Message:

< [body] [CR]

- [body] – Body of the command
- [CR] – Carriage Return (value 0x0D)

## General error

In case of syntax error or not supported command general error message is issued.

#### Answer:

<ERR [CR]

## Communication test

#### Command:

> [CR]

#### Answer:

<OK [CR]

---

---

## Commands

Some older IQRF USB devices support no CDC at all or only a subset of commands described in this guide. See [Table\\_1](#) below for supported devices with respect to the firmware inside.

### Reset USB Device

5 s after receiving of this command the USB device is reset. This delay allows to disconnect USB communication on PC side in time.

*Command:*

```
>R[CR]
```

*Answer:*

```
<R:OK[CR]
```

### Reset TR Module

TR module inside the USB device is reset.

*Command:*

```
>RT[CR]
```

*Answer:*

```
<RT:OK[CR]
```

### Get USB Device Info

Returns USB device identification.

*Command:*

```
>I[CR]
```

*Answer:*

```
<I:[type]#[version]#[id][CR]
```

```
[type]    - Device type (in text format)
[version] - Firmware version (in text format)
[id]      - Serial number (in text format)
```

*Example:*

```
>I[CR]
```

```
<I:GW-USB-03#02.01#03010000[CR]
```

```
[type]    - GW-USB-03
[version] - 2.01
[id]      - 0x03010000
```

## Get TR Module Info

Returns identification of TR module inside the USB device.

**Command:**

```
>IT[CR]
```

**Answer:**

```
<IT:[module_info][CR]
```

[module\_info] – Description see *IQRF OS Reference guide* (function `moduleInfo`).

- For IQRF OS v4.02D or lower: 8 B Module Info (LSB first) and 8 B dummy data is returned.
- For IQRF OS v4.03D or higher: 8 B Module Info (LSB first), 8 B dummy data and 16 B IBK (Individual Bonding Key) is returned.

The TR module in CK-USB-04A is allowed to be plugged / unplugged into / from the SIM connector while powered off only (e.g. while the SW2 pushbutton is held). If TR is plugged in without the CK-USB-04A reset, the *IT* answer is not valid for CK-USB-04A with FW lower than v1.11.

For CK-USB-04A with FW v1.11 or higher the answer takes about 300 ms.

For GW-USB-06 with FW v1.06 or higher the answer takes about 2 s if the device is not in programming mode.

## Connectivity Indication

USB device issues an acoustical or optical indication.

**Command:**

```
>B[CR]
```

**Answer:**

```
<B:OK[CR]
```

## Get Status

Returns information about current status.

**Command:**

```
>S[CR]
```

**Answer:**

```
<S:[spi_status][CR]
```

[spi\_status] - Value according to the table in *IQRF SPI User's guide* (chapter *SPI status*)

## Send Data

Sends data to TR module inside the USB device.

### Command:

>DS[dlen]:[data][CR]

- [dlen] – Data length (number of bytes in the [data] field), in hexadecimal
  - Range 1 to 41
  - Range 1 to 64 (GW-USB-05 and CK-USB-04A)
- [data] – Actual data for TR module
  - Number of bytes must correspond to [dlen]

### Answers:

<DS:OK[CR]

Data successfully sent to TR module

<DS:ERR[CR]

- Communication failure (checksum error)
- [dlen] out of range
- Data length mismatch (number of bytes in [data] does not correspond to [dlen])

<DS:BUSY[CR]

- SPI bus is busy, communication is just running
- TR module is not in communication mode

### Example:

>DS[0x05]:Hello[CR]

<DS:OK[CR]

## Receive Data

Asynchronous message sent by the USB device after data receipt from TR module.

### Messages:

<DR[dlen]:[data][CR]

- [dlen]
  - Data length (number of bytes in the [data] field), in hexadecimal
  - Range 1 to 41
  - Range 1 to 64 (GW-USB-05)
- [data] Actual data from TR module

<DR:ERR[CR]

Communication failure (checksum error)

### Example:

<DR[0x05]:Hello[CR]

---

---

**Switch to USB Custom Class**

USB class is switched to Custom and the device is reset 5 s after this command is issued. This delay allows to cancel USB communication on PC side. Refer to user's manual of given USB device how to return to CDC.

*Command:*

```
>U [CR]
```

*Answer:*

```
<U:OK [CR]
```

**Switch to USB CDC – UART**

USB device is switched to CDC – UART transparent mode and the device is reset 5 s after this command is issued. This delay allows to cancel USB communication on PC side. Refer to user's manual of given USB device how to return back.

*Command:*

```
>UU [CR]
```

*Answer:*

```
<UU:OK [CR]
```

**Switch to USB CDC - SPI**

USB device is switched to CDC – SPI transparent mode and the device is reset 5 s after this command is issued. This delay allows to cancel USB communication on PC side. Refer to user's manual of given USB device how to return back.

*Command:*

```
>US [CR]
```

*Answer:*

```
<US:OK [CR]
```

---

---

## Upload commands

### Enter programming mode

Enter programming mode of TR module inside the USB device.

*Command:*

```
>PE [CR]
```

*Answers:*

```
<PE:OK [CR]
```

TR module is in programming mode.

```
<PE:ERR1 [CR]
```

TR module is not in programming mode.

### Terminate programming mode

Terminate programming mode of the TR module inside the USB device.

*Command:*

```
>PT [CR]
```

*Answer:*

```
<PT:OK [CR]
```

TR module programming mode is terminated.

```
<PT:ERR1 [CR]
```

- Communication failure
- TR module is still in programming mode

## Upload/download TR memory

Command *PM* allows to upload/download data to/from TR module inside the USB device.  
General format of *PM* command is:

```
>PM[target][addr_L][addr_H][data][CR]
    [target]    Specifies upload/download operation and the target memory
    [addr_L]    Specifies low address of tagret memory
    [addr_H]    Specifies high address of tagret memory
    [data]      Data to be uploaded
```

Format of [target]:

bit7: Operation: 1 - Upload, 0 - Download

bit6, bit5, bit4: Reserved for future use, should be cleared

bit3, bit2, bit1, bit0: Specifies TR module memory to upload/download

**Answers:**

<PM:OK[CR]

Data successfully sent to TR module, TR module is in programming mode, next data can be sent.

<PM:ERR2[CR]

Incorrect [target] memory

<PM:ERR3[CR]

Incorrect [data] length

<PM:ERR4[CR]

Incorrect [addr\_L][addr\_H] address

<PM:ERR5[CR]

Specified [target] memory is write only.

<PM:ERR6[CR]

Communication failure, upload/download error

<PM:ERR7[CR]

Operation is not supported by TR module (e.g. TRs with 0S 3.xx does not support *Access key* and *User key*)

<PC:BUSY[CR]

- SPI bus is busy, communication is running.
- TR module is not in programming mode.

When uploading the memories from a .HEX file, the addresses must be properly interpreted with respect to mapping of individual memory types into a single virtual space. E.g., the CC5X compiler generates virtual addresses from physical addresses in EEPROM by adding the offset 0x0200. See table *Virtual and physical addresses* below. For the HEX format description, refer to *CC5X C compiler User's guide* (included in IQRF IDE) or *IQRF DPA Framework Technical guide*, chapter *Custom DPA Handler Code at .hex File*.

**Caution:** All addresses in .HEX files generated by CC5X compiler are multiplied by two.

Therefore, when handling with memories according to all the commands described below, all addresses read from a .HEX file must be divided by two first.

All addresses mentioned below mean the resulting addresses (thus divided by two already).

Individual memory types (see below) can be uploaded in any order, with the only exception: if the .IQRF file as well as the *Access password* and/or *User key* are to be uploaded, the .IQRF file must be uploaded sooner.

**Tip:** Upload the *Access password* and *User key* as the last one(s).



### Virtual and physical addresses

Virtual address (in .HEX)	Flash					EEPROM	EEPROM	
	Physical address	Standard	Extended	Configuration	OS	Physical address	Physical address	
0000	0000				Accessible via Special upload from .IQRF file only	0000		
.	.							
0200								Addressable by #pragma
.								
0400								
.								
09FF								07FF
0A00								0800
.	.							
.	.						2BFF	
.	.		2C00					
.	.		.					
.	.		37BF					
.	.			37C0				
.	.			.				
.	.			37DF				
.	.							
.	.					37E0		
.	.					.		
.	.					39FF		
.	.	3A00						
.	.	.						
3FFF	3FFF	3FFF						
4000							3E00	
.								
41FF							3FFF	
4200	Unused							
.								
EFFF								
F000						00		
.						.		
F0FF						FF		

## Upload TR configuration

Upload/download configuration to/from TR module inside the USB device.

### Upload command:

```
>PM[target] [data] [CR]
    [target 0x80]           Specifies TR configuration upload
    [data[0]]               XOR of all configuration bytes with initial value 0x5F
    [data[1]-data[31]]     Configuration (31 B). See IQRF DPA Framework Technical guide, chapter HWP configuration .
```

### Answers:

See chapter Upload/download TR module memory

### Download command:

```
>PM[target] [CR]
    [target 0x00]           Specifies TR configuration download
```

### Answer:

```
<PM[data] [CR]
    [data[0]]               XOR of all configuration bytes with initial value 0x5F
    [data[1]-data[31]]     Configuration (31 B)
```

## Upload TR RFPGM configuration

Upload/download RFPGM configuration to/from the TR module inside the USB device.

### Upload Command:

```
>PM[target] [data] [CR]
    [target 0x81]           Specifies TR RFPGM configuration upload
    [data]                   RFPGM configuration – 1 B. See IQRF OS Ref. guide, function setupRFPGM() .
```

### Answers

See chapter Upload/download TR module memory.

### Download command:

```
>PM[target] [CR]
    [target 0x01]           Specifies TR RFPGM configuration download
```

### Answer:

```
<PM[data] [CR]
    [data]                   RFPGM configuration – 1 B. See IQRF OS Ref. guide, funxtion setupRFPGM() .
```

## Upload TR RF band configuration

Upload/download RF band configuration to/from the TR module inside the USB device.

### Upload Command:

```
>PM[target] [data] [CR]
   [target 0x82]   Specifies TR RF band configuration upload
   [data          ]   RF band configuration
                   0x00   868 MHz
                   0x01   916 MHz
                   0x02]   433 MHz
```

### Answers

See chapter Upload/download TR module memory.

### Download command:

```
>PM[target] [CR]
   [target 0x02]   Specifies TR RF band configuration download
```

### Answer:

```
<PM[data] [CR]
   [data          ]   RF band configuration – 1 B
```

## Upload TR Access password

Upload Access password to the TR module inside the USB device. Access password is write-only, can not be downloaded.

### Upload command:

```
>PM[target] [data] [CR]
   [target 0x83]   Specifies TR Access password upload
   [data          ]   Access password – 16 B
```

### Answers:

See chapter Upload/download TR module memory.

## Upload TR User key

Upload User key to TR module inside the USB device. User key is write-only, can not be downloaded.

### Upload command:

```
>PM[target] [data] [CR]
   [target 0x84]   Specifies TR User key upload
   [data          ]   User key – 16 B
```

### Answers:

See chapter Upload/download TR module memory.

## Upload TR Flash program memory

Upload/download Flash memory of TR module inside the USB device.

### Upload command:

```
>PM[target] [addr_L] [addr_H] [data] [CR]
    [target 0x85]    Specifies TR Flash memory upload
    [addr_L]         Low address
    [addr_H]         High address
    [data]           Data to be uploaded – 32 B (16 instructions) in little endian order
```

### Conditions:

```
[addr_L] [addr_H]    Address should be modulo 16 and should point to:
                    – Application memory: Area 0x3A00 – 0x3FFF (1536 machine instructions)
                    – Extended Flash memory: Area 0x2C00 – 0x37BF (3008 machine instructions)
                    See table Virtual and physical addresses above.
```

### Answers:

See chapter Upload/download TR module memory.

### Download command:

```
>PM[target] [addr_L] [addr_H] [CR]
    [target 0x05]    Specifies TR Flash download
    [addr_L]         Low address
    [addr_H]         High address
```

### Conditions:

```
[addr_L] [addr_H]    Address should be modulo 32 and should point to:
                    – Application memory: Area 0x3A00 – 0x3FFF (1536 machine instructions)
                    – Extended Flash memory: Area 0x2C00 – 0x37BF (3008 machine instructions)
                    See table Virtual and physical addresses above.
```

### Answer:

```
<PM[xor data] [CR]
    [xor data]       Device returns 32 B:
                    instr.low8[addr] XOR instr.high8[addr]
                    instr.low8[addr+1] XOR instr.high8[addr+1]
                    ...
                    instr.low8[addr+31] XOR instr.high8[addr+31]
```

---

**Upload TR internal EEPROM memory**

Upload/download internal EEPROM of TR module inside the USB device.

**Upload command:**

```
>PM[target] [addr_L] [addr_H] [data] [CR]
   [target 0x86]   Specifies TR internal EEPROM upload
   [addr_L]        Low address
   [addr_H]        High address
   [data]          Data to be uploaded, 1-32 bytes
```

**Conditions:**

[addr\_L] [addr\_H] Address should point to area 0x0000 – 0x00BF. The sum of address and data length should be < 0x00C0.

**Answers:**

See chapter Upload/download TR module memory.

**Download command:**

```
>PM[target] [addr_L] [addr_H] [CR]
   [target 0x06]   Specifies TR internal EEPROM download
   [addr_L]        Low address
   [addr_H]        High address
```

**Conditions:**

[addr\_L] [addr\_H] Address should point to area 0x0000 – 0x00A0.

**Answer:**

```
<PM[data] [CR]
   [data]          Internal EEPROM content – 32 B
```

---

---

## Upload TR external EEPROM memory

Upload/download external EEPROM of TR module inside the USB device.

### Command:

```
>PM[target] [addr_L] [addr_H] [data] [CR]
   [target 0x87]   Specifies TR external EEPROM upload
   [addr_L]        Low address
   [addr_H]        High address
   [data]          Data to be uploaded – 32 B
```

### Conditions:

[addr\_L] [addr\_H]            Address should be modulo 32 and point to area 0x0000 – 0x3FE0

### Answers:

See chapter Upload/download TR module memory.

### Download command:

```
>PM[target] [addr_L] [addr_H] [CR]
   [target 0x07]   Specifies TR external EEPROM download
   [addr_L]        Low address
   [addr_H]        High address
```

### Conditions:

[addr\_L] [addr\_H]            Address should point to area 0x0000 – 0x3FE0

### Answer:

```
<PM[data] [CR]
   [data]          External EEPROM content – 32 B
```

## Special upload

Upload data from .IQRF file to the TR module inside the USB device.

### Command:

```
>PM[target] [data] [CR]
   [0x88]          Specifies special upload
   [data]          Data to be uploaded
```

### Conditions:

[data]            Should contain 1 line of an \*.iqrf file

### Answers:

See chapter Upload/download TR module memory.

## CDC commands overview

Function		Command	Target	Blocks	
Communication test		<i>Blank</i>			
Reset USB Device		R			
Reset TR Module		RT			
Get USB Device Info		I			
Get TR Module Info		IT			
Connectivity Indication		B			
Get Status		S			
Send Data		DS		Up to 41 or 64 B	
Receive Data		DR		Up to 41 or 64 B	
Switch to USB Custom Class		U			
Switch to USB CDC – UART		UU			
Switch to USB CDC - SPI		US			
Enter programming mode		PE			
Terminate programming mode		PT			
Upload	Flash	Write application	PM	85	16 words
		Verify application		05	32 B
	Plug-in	Write		88	1 line
		Configuration		Write OS – RF band	82
	Read OS – RF band			02	1 B
	Write OS – RFPGM			81	1 B
	Read OS – RFPGM			01	1 B
	Write HWP			80	32 B
	Read HWP			00	32 B
	Write Security – Access password			83	16 B
	Write Security – User key			84	16 B
	EE	Write		86	Up to 32 B
		Read		06	32 B
	EEE	Write		87	32 B
		Read		07	32 B

## Supported devices

Command / Message		CK-USB-04	CK-USB-04A	GW-USB-03	GW-USB-03A	GW-USB-04	GW-USB-05	GW-USB-06	GW-USB-07
R	Reset USB device	-	1.01	2.03	1.00	1.20	1.03	1.00	1.00
RT	Reset TR module	-	1.01	2.03	1.00	1.20	1.03	1.00	1.00
I	Get USB Device Info	-	1.01	2.03	1.00	1.20	1.03	1.00	1.00
IT	Get TR Module Info	-	1.01	2.03	1.00	1.20	1.03	1.00	1.00
B	Connectivity Indication	-	1.01	2.03	1.00	1.20	1.03	1.00	1.00
S	Get Status	-	1.01	2.03	1.00	1.20	1.03	1.00	1.00
DS	Send Data	-	1.01	2.03	1.00	1.20	1.03	1.00	1.00
DR	Received Data	-	1.01	2.03	1.00	1.20	1.03	1.00	1.00
U	Switch to USB Custom Class	-	1.01	2.03	1.00	1.20	1.03	1.00	1.00
UU	Switch to USB CDC – UART	-	1.10	-	-	-	1.07	1.04	1.00
US	Switch to USB CDC - SPI	-	1.10	-	-	-	1.07	1.04	1.00
PE	Enter programming mode	-	-	-	-	-	-	1.07 *	1.00
PT	Terminate programming mode	-	-	-	-	-	-	1.07 *	1.00
PM	Upload/download TR memory	-	-	-	-	-	-	1.07 *	1.00

\* Commands PE, PT and PM are available also for GW-USB-06 with FW v1.06 but with IQRF OS v4.00D only.

Table 1 – Commands supported by individual IQRF USB devices with respect to FW inside.

## Document history

- 200918 URL links slightly updated.
- 181018 Updated for IQRF OS v4.03D (IBK included in *Get TR Module info*). References to the HEX format description added into chapter *Upload / download TR memory*.
- 180319 Upload revised and extended. Tables *Virtual and physical addresses* and *CDC commands overview* added.
- 171018 Chapter *Upload/download TR memory* extended (the last paragraph and a *Tip* added).
- 170810 TR transceiver upload in IQRF CDC USB mode added.
- 150806 Extended for GW-USB-06. Chapters *CDC class* and *Get TR Module Info* revised.
- 150119 Extended for CDC SPI and CDC UART modes.
- 140129 CK-USB-04A support added.  
Document file renamed from MNCDC\_130121 to User\_Guide\_CDC\_140129.
- 130121 GW-USB-05 support added.
- 121008 First chapter extended. Bugs in *Switch to USB Custom Class* and *Reset USB Device* fixed.
- 110526 *Switch to USB Custom Class* command added.
- 110318 First release.



---

## Sales and Service

---

### Corporate office

IQRF Tech s.r.o., Prumyslova 1275, 506 01 Jicin, Czech Republic, EU  
Tel: +420 493 538 125, Fax: +420 493 538 126, [www.iqrf.tech](http://www.iqrf.tech)  
E-mail (commercial matters): [sales@iqrf.org](mailto:sales@iqrf.org)

### Technology and development

[www.iqrf.org](http://www.iqrf.org)  
E-mail (technical matters): [support@iqrf.org](mailto:support@iqrf.org)

### Partners and distribution

[www.iqrf.org/partners](http://www.iqrf.org/partners)

---

### Quality management

ISO 9001 : 2009 certified

### Trademarks

*The IQRF name and logo are registered trademarks of IQRF Tech s.r.o.  
PIC, SPI, Microchip and all other trademarks mentioned herein are property of their respective owners.*

### Legal

*All information contained in this publication is intended through suggestion only and may be superseded by updates without prior notice. No representation or warranty is given and no liability is assumed by IQRF Tech s.r.o. with respect to the accuracy or use of such information.*

*Without written permission it is not allowed to copy or reproduce this information, even partially.*

*No licenses are conveyed, implicitly or otherwise, under any intellectual property rights.*

*The IQRF® products utilize several patents (CZ, EU, US)*

---

---

**On-line support: [support@iqrf.org](mailto:support@iqrf.org)**

---